

Listen to the ocean

# Challenges of and needs for monitoring the size of small particles by Argo-derived optical proxies

Emanuele Organelli, Giorgio Dall'Olmo, Robert Brewin, Glen Tarran and Gavin Tilstone Prospect Place, The Hoe, PL1 3DH Plymouth UK

emo@pml.ac.uk











## **Outlines**

- 1. Introduction
- 2. Methods
- 3. Results
- 4. Implications for BGC-Argo floats
- 5. Take home messages

## Introduction

PML Plymouth Marine Laboratory







Algal photosynthesis is the most important pathway of production of organic particles in the ocean. Thereafter, these particles can:

> aggregate be grazed be fragmented be remineralised to  $CO_2$ sink to the abyss

The *size* of particles governs all these processes, and varies over the time and depth

U.S. JGOFS (2001)

Plymouth Marine

PML



Algal photosynthesis is the most important pathway of production of

"Observing particle and plankton size distributions (PSDs) in a synoptic manner could help to better understand the processes contributing to the biological pump" (Stemmann and Boss, Ann. Rev. Mar. Sci. 2011)



sink to the abyss

The **size** of particles governs all these processes, and varies over the time and depth

U.S. JGOFS (2001)

Plymouth Marine Laboratory

PML

#### The size of marine particles and how to measure PSDs



PML

Plymouth Marine Laboratory

#### The size of marine particles and how to measure PSDs



PML

Plymouth Marine Laboratory

#### **Coulter Counter**



## Particles (0.2-20 µm) interact with light



Attenuation= Absorption + Scattering

$$c_p(\lambda) = a_p(\lambda) + b_p(\lambda)$$

(called IOPs)



Boss et al. (2013)

PML Plymouth Marine Laboratory



PML

Plymouth Marine Laboratory

The slope,  $\eta$ , of the particle backscattering coefficient ( $b_{bp}(\lambda)$ ) can be used as a proxy of the PSD slope,  $\xi$ 



The slope,  $\gamma$ , of the beam attenuation coefficient ( $c_p(\lambda)$ ) can be used as a proxy of the slope,  $\xi$ , of the Particle Size Distribution (PSD)



## **The potential of Biogeochemical Argo floats**



#### **BGC-Argo floats for:**

PML Plymouth Marine Laboratory

Monitoring changes in particle size and concentration using  $b_{bp}(\lambda)$ -derived optical proxies. This could help improving our understanding of the pathways of the biological pump processes, and of the magnitude and variability of carbon fluxes in the mesopelagic region.

#### Critical need (aim of the talk):

To understand how the relationships between PSDs and optical proxies vary spatially and temporally, from the surface to the ocean interior.



## **Methods**

PML Plymouth Marine Laboratory



#### **PSDs and optical proxies from the Atlantic Meridional Transect**

**AMT22** Oct.–Nov. 2012

PML Plymouth Marine Laboratory



**PSD** (coulter counter): 1.4-42 μm **Optics**: ac-s & bb3 1 depth: 5 m (ship's underway samples)

**AMT26** Sep.–Nov. 2016



**PSD** (coulter counter): 0.55-60  $\mu$ m **Optics**: ac-9 & Hydroscat-6 6 depths: 5 to 500 m (cast samples)



## **Results**

## **PSD** and optical proxies (at 5 m)



#### backscattering

PML | Plymouth Marine Laboratory

Organelli et al. in prep.

#### **PSD** and optical proxies (at 5 m)

PML Plymouth Marine Laboratory



Organelli et al. in prep.

#### **PSD** and optical proxies (at 5 m)

γ
(based on more than 2 wavelengths)
is a proxy of the relative
contribution of large and small
(living and not) particles

as well as of the algal community structure...not shown





PML Plymouth Marine

Useful measurement currently unavailable on BCG-floats



PML | Plymouth Marine Laboratory

AMT26

 ${
m b_{bp}}(\lambda)$  slope  $\eta$  (5 wavelengths between 442-671 nm)



Large-to-Small particles (1µm) (from Coulter)







#### **Implications for BGC-Argo floats**



## Can we infer PSDs from current BCG-Argo configuration (b<sub>bp</sub> at 532 and 700 nm)?





PML | Plymouth Marine Laboratory





#### What can we do next?



 $6\lambda\lambda = 442$  to 852 nm





 $\eta$  float

 $\eta$  Multispectral (442-671 nm)



#### PML Plymouth Marine Laboratory

#### Take home messages





PML Plymouth Marine

- Current backscattering measurements on BGC-Argo floats can mislead our interpretation about small particle size (at least in the oligotrophic Atlantic Ocean)
- Future BGC-Argo floats may be equipped with b<sub>bp</sub>(442) and b<sub>bp</sub>(671) or b<sub>bp</sub>(852), or at least 2 wavelengths covering a broad spectral range
- Measurements of the spectral beam attenuation coefficient could further help understanding changes in the contribution of large-tosmall particles and of the algal community structure



## **Thanks!**



This study has been supported by the **REOPTIMIZE** project which has received funding from the **European Union's Horizon 2020** research and innovation programme under the **Marie Skłodowska-Curie** grant agreement No 706781.

